

# MOUNTING GUIDELINES WINTEX 2000



## MOUNTING THE WINTEX 2000 ON A TRACTOR

---

The WINTEX 2000 is delivered with a 12 V socket which must be connected to 12 V plug of the tractor.

### CONNECTION OF HOSES:

Hose P must be connected to the hydraulic pressure port of the tractor.

Hose R must be connected to the hydraulic return port of the tractor.

Hose T must be connected to the directly to the pressureless return port of the tractor.\*

\* In case that the tractor does not have a pressureless return port, it must be established.

